

VertiKlean MAX Mop Wipe System

Versatile, lightweight mop wipe system

Contec's VertiKlean MAX Mop Wipe System offers a quick and easy solution to mopping floors, walls, and ceilings in any controlled environment. This versatile mop works with a variety of Contec mop wipes enabling the user to eliminate the use of water in the cleanroom.

The VertiKlean MAX Mop Wipe frame has been fitted with robust and easy to use "keepers". Used with a standard microfibre or sealed edge VertiKlean MAX mop head, the system can then be fitted with a choice of dry, presaturated or saturated at point of use mop wipes. The VertiKlean MAX Mop Wipe frame easily attaches to any Contec QuickConnect handle, allowing use in a wide variety of applications and facilities.

The use of the VertiKlean MAX mop head provides excellent surface contact and conformity on uneven surfaces. The system can then be used to apply disinfectant solutions, dry and wet cleaning, residue removal or wiping-to-dry.



For maximum versatility, Contec offers dry and presaturated mop wipes for the VertiKlean MAX Mop Wipe Frames.

FEATURES	BENEFITS
Stainless steel frame with flexible keepers	<ul style="list-style-type: none"> • Good chemical resistance • Autoclavable; can be sterilized by most common methods including gamma irradiation, ethylene oxide, or autoclave (recommended cycle is 121°C for 30 minutes) • Easy to attach and remove mop covers
Disposable single-use mop wipes	<ul style="list-style-type: none"> • Variety of fabric options available • Presaturated or dry wipes for saturation at point of use are available • Removes contaminants easily and completely from the environment • Extends the life of the VertiKlean MAX mop head
Presaturated mop wipes	<ul style="list-style-type: none"> • Eliminates the need for a bucket and wringer
Lightweight design and slim profile	<ul style="list-style-type: none"> • Allows easy access to confined spaces for efficient cleaning and disinfection • Easier to clean floors, walls, and ceilings

MOP WIPES

Polyester/Cellulose

Highly sorbent and suitable for removal of light soils, residues and biofilms. Most cost effective option. Available sterile and non sterile.

Quiltec

Cleanroom laundered, 100% polyester knit ensures a very low level of particulates. It is very absorbent and durable – suitable for large surface areas and for use where superior sorbency is required. Available dry and presaturated.

MicroGenesis

Microfibre is excellent for removing powder residue on equipment, walls, floors and ceilings, also grease from production equipment between manufacturing jobs. Superior spill pick-up and removal.



Mop wipes fit easily around the 2651K or 2652K VertiKlean MAX Mop Wipe frame to extend the life of the foam mop head.

Part No	Description	Size	Packaging
Mop Head			
2652K	VertiKlean MAX Mop Wipe Frame Medium	29cm	Each
VKMX0225	Medium VertiKlean MAX Mop Head	32 x 11 x 2cm	4 mops x 7 bags
VKMX0275	Medium VertiKlean MAX Mop Head Sterile	32 x 11 x 2cm	1 mop x 28 bags
VKSE0200	Medium VertiKlean MAX Sealed Edge Mop Head	38 x 13 x 1cm	4 mops x 4 bags
VKSE0250	Medium VertiKlean MAX Sealed Edge Mop Head Sterile	38 x 13 x 1cm	1 mop x 24 bags
Mop Wipes			
LWQT0100	Quiltec I 100% 2-ply polyester mop wipes	42 x 25cm	20 wipes x 12 bags
PSQT0100	PROSAT Sterile Quiltec I 100% 2-ply polyester with 70% IPA (folded)	42 x 25cm	20 wipes x 9 bags
NWCP0100	Amplitude Sigma 68gsm polyester / cellulose mop wipe	40 x 30cm	50 wipes x 20 bags
NWCP0100IR	Sterile Amplitude Sigma 68gsm polyester / cellulose mop wipe	40 x 30cm	20 wipes x 30 bags
LWMM0300	Microgenesis Microfibre mop wipe	46 x 25cm	100 wipes x 4 bags
Handles			
2725E	QuickConnect Handle Stainless Steel One Piece	150cm	Each
2642	QuickConnect Telescopic Handle Anodised Aluminium	40 - 75cm	Each
2643	QuickConnect Telescopic Handle Anodised Aluminium	130 - 230cm	Each

For more QuickConnect handle options, visit our website: www.contecinc.com

A smaller VertiKlean MAX Wipe frame is also available, which is ideal for use in any mini-environment, eg isolators, RABS, UDAF and biological safety cabinets. The smaller head in conjunction with a VKSE sealed edge mop head can be used with any 230 x 280 mm presaturated wipe. Using a VKMAX mop head any 300 x 300 mm wipe can be used.

Part No	Description	Size	Packaging
Mop Head			
2651K	VertiKlean MAX Wipe Frame Regular	19cm	Each
VKMX0125	Regular VertiKlean MAX Mop Head	21 x 11 x 2cm	4 mops x 12 bags
VKMX0175	Regular VertiKlean MAX Mop Head Sterile	21 x 11 x 2cm	1 mop x 48 bags
VKSE0100	Regular VertiKlean MAX Sealed Edge Mop Head	21 x 11 x 1cm	4 mops x 10 bags
VKSE0150	Regular VertiKlean MAX Sealed Edge Mop Head Sterile	21 x 11 x 1cm	1 mop x 40 bags

For wipes options, visit our website: www.contecinc.com

For more information or to request a sample please email infoeu@contecinc.com or phone 00 33 (0)2 97 43 76 98.



infoeu@contecinc.com
www.contecinc.com